

BT-WSR/S WIRELESS BLUETOOTH WALL SWITCH



PRODUCT DESCRIPTION


- Powered by two CR2032 batteries
- Blue tooth communication
- No wires needed
- Easy installation for surface-mounted or recessed in the wall, or just leave it on the desk
- When low power, press any buttons and the red light flashes

PERFORMANCE AND ELECTRICAL DATA


Communication Mode	Bluetooth
Supply Voltage	3V
Flame Rating	UL 94 V-0
Working Humidity	≤90%RH
Working Temperature	-10-45°C
Net Weight	8.3g

INSTRUCTIONS

1. Install 2pc CR2032 battery by opening the back cover.
2. Press button 1 and 2 together over seconds to enter pairing the mode or achieve reset function. This switch can be scanned in next 30 seconds.
3. In Keilton App "Switch" page, click to add switch.
4. Select the light/light group to be controlled this switch.
5. Select 3 scenes to be controlled by this switch.



PRODUCT DIMENSIONS






Quotations: quotes@jademar.com
To place an order: orders@jademar.com
Tel: (305) 640.0465 | Fax: (305) 640.0468
WWW.JADEMAR.COM






Information contained herein is subject to change without notice.
Revised 12/2024

JADEMAR[®] BT-WSR/S WIRELESS BLUETOOTH WALL SWITCH

INSTALLATION INSTRUCTIONS

Step 1: Pry up the cover of Remote Controller with a flat screw driver.	Step 2: Replace the battery with new one.	Step 3: Attach the cover.
		

WALL INSTALLATION

Step 1: Remove the cover plate carefully with scissors.	Step 2: Mark a position you want to install.	Step 3: Drill the holes with power drill.
		
Step 4: Attach the Bracket with supplied self-tapping screws.	Step 5: Attach the Bracket with supplied self-tapping screws.	Step 6: Attach the wallplate.
